

SAFETY INSTRUCTION SHEET



BATTERY SAFETY INFORMATION



CAUTION



In Exceptional Circumstances Batteries May Leak Fluids That Can Cause A Chemical Burn, Injury, Or Ruin Your Product. To Avoid Battery Leakage;

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).
- Rechargeable batteries are only to be charged under adult supervision (if designed to be removed).
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.



WARNING:



WARNING : Do not dispose of this product in a fire. Batteries inside may explode or leak.



WARNING:



CHOKING HAZARD : Small parts. Not for children under 3 yrs.

MAGNET WARNING



WARNING:



WARNING : This product contains a magnet. Do not use around items that are sensitive to or affected by magnetic fields.

SMALL BALL PARTS WARNING



WARNING



CHOKING HAZARD : Toy contains a small ball. Not for children under 3 yrs.

PROJECTILE WARNING



WARNING



CHOKING HAZARD : Only use projectiles supplied with this toy. DO NOT fire at people or animals or at point blank range.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



ROBOT BIRTHDAY PARTIES

GALAXY FIELD TRIPS

ONLINE GAMES & MORE

WWW.ROBOTGALAXY.COM

US Patent No. 561211-216, 561793, 561795-797

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

THE ROBOT FACTORY, LLC. 41 UNION SQUARE WEST, #808, NY, NY 10003




MISSION BRIEFING

**T O P S E C R E T
I N S T R U C T I O N S**


FOR AGES 5 YRS +

ROBOT ASSEMBLY



IMPORTANT

MAKE SURE THE **FLEXOR** IS FLUSH TO THE **CORE** BEFORE ATTACHING WITH **HEX KEY**




FUEL CELL

HOW TO USE YOUR FUEL CELL



FUEL CELL

| | A | SWITCH | B |
|------------------------------------|----|--------|----|
| ACTIVATE LEFT FLEXOR AND EXTENDER | ✓ | | |
| ACTIVATE RIGHT FLEXOR AND EXTENDER | | | ✓ |
| ACTIVATE LEFT SIDE CONTINUOUSLY | ✓* | | |
| ACTIVATE RIGHT SIDE CONTINUOUSLY | | | ✓* |
| TOGGLE FOR CHARACTER MODE | | ✓ | |



PLEASE KEEP THIS INSTRUCTION SHEET FOR FUTURE REFERENCE, AS IT CONTAINS IMPORTANT INFORMATION.

ASSEMBLED BY RG EXPLORERS
MADE IN CHINA

SUPERSONIC FUEL CELL

HOW TO PLAY WITH YOUR ROBOT



CONNECT TO ONLINE GALAXY

- STEP #1** PLUG IN USB CABLE TO COMPUTER
- STEP #2** GO TO ROBOTGALAXY.COM
- STEP #3** CLICK "PLAY" AND ENTER THE ONLINE GALAXY
- STEP #4** FOLLOW ON-SCREEN INSTRUCTIONS

FUEL CELL BUTTONS

| | A | B | C |
|------------------------------------|----|----|----|
| ACTIVATE NICKNAME | ✓ | ✓ | ✓ |
| ADJUST VOLUME DOWN (-) | | ✓ | ✓ |
| ADJUST VOLUME UP (+) | ✓ | ✓ | |
| ACTIVATE POWER SEQUENCE | | ✓* | |
| ACTIVATE ROBOT VOICE | | ✓ | |
| ACTIVATE LEFT FLEXOR AND EXTENDER | ✓ | | |
| ACTIVATE RIGHT FLEXOR AND EXTENDER | | | ✓ |
| TOGGLE FOR CHARACTER MODE | ✓ | | ✓ |
| ACTIVATE LEFT SIDE CONTINUOUSLY | ✓* | | |
| ACTIVATE RIGHT SIDE CONTINUOUSLY | | | ✓* |

*HOLD BUTTON FOR 2 SECONDS OR MORE