



FLY WORLD APPLICATION USER MANUAL VERSION 1.0

FOR WINDOWS XP AND VISTA

TABLE OF CONTENTS

System Requirements	3	• What's on My FLY Fusion Pentop Computer	26
Software Compatibilities	3		
Frequently Asked Questions	4	• What's on My Cartridge	30
Quick Tips	5	• Managing Memory	31
• Notebooks	5	• Adding Applications to the Cartridge	31
• Pentop	5	• Removing Applications from the Cartridge	32
• Download Store	5	• Adding and Deleting MP3s	33
• FLY World Admin Account	6	• Syncing Your FLY Fusion Pentop Computer	34
FLY World Profiles and Accounts	7	The Download Store Tab	36
Installing the FLY World Application	8	• Navigating the FLY World Download Store	36
Uninstalling the FLY World Application	8	• Searching	36
PENTOP PROFILES	9	• Viewing Product Details	37
Overview	9	• Buying and Downloading	38
Creating a Pentop Profile	9	• Permissions	39
Logging On to the FLY World application with a Pentop Profile	10	THE FLY WORLD ADMIN ACCOUNT	40
Help, Settings, and Logging Off	10	Overview	40
The Notebooks Tab	14	Creating the FLY World Admin Account	40
• Converting Your Recorded Writing	15	Logging On to the FLY World Application with an Admin Account	41
• Managing Your FLY Fusion™ Notebooks	15	The Pentop Users Tab	42
• Searching Your FLY Fusion Notebooks	20	The Manage Accounts Tab	43
• Previewing Notebook Pages	20	• Manage Pentop Users: Select Pentop Users to Manage	43
• Printing Notebook Pages	21	• Manage Pentop Users: Set Permissions	44
• E-mailing Notebook Pages	22	• Manage Pentop Users: Subscriptions	45
• Saving Notebook Pages as Images	23	• Manage Pentop Users: Add Value	45
• Opening Notebook Pages as Documents	23	• Your Account: Account Information & Preferences	46
• Image Selection Tool	24	Your Account: Credit Card Information	46
The Pentop Tab	25	The Admin Download Store Tab	47
• My Applications	25	FLY World Support and Contact Information	47
• Application Updates	26		


WELCOME TO THE FLY WORLD APPLICATION!

Welcome to the next generation of Pentop Computing! Your experience will include three essential components: your FLY Fusion™ Pentop Computer, the FLY World application, and the FLY World Download Store.

FLY Fusion Pentop Computer: A powerful computer you can hold in your hand! It can do math, schedule activities, help you with homework, save class notes, make music, and play games. It goes where you go and it doesn't need a keyboard. It reads and understands what you write, and talks back to you. It comes loaded with applications (called FLY Fusion software) that can do lots of cool things. You can hook it up to your personal computer to upload your notes or download more applications. For more information about the FLY Fusion Pentop Computer, see the *FLY Fusion Pentop Computer User Manual* (available online or on the included CD).

FLY World application: A fun and easy-to-use application for managing your FLY Fusion Pentop Computer! The FLY World application lets you swap out FLY Fusion software and MP3s on your Pentop Computer, customizing it to your exact needs. With the FLY World application you can also save all your FLY Fusion Notebooks electronically! You can upload notebook pages to view and save on your computer. You can also print or e-mail notebook pages to your friends.

FLY World Download Store: Where you can shop for FLY Fusion software for your Pentop Computer. Choose from a growing library of homework help tools, puzzles, games, and more!



SYSTEM REQUIREMENTS

- Windows® XP operating system
- Windows Vista™ operating system supported
- Pentium® III 500MHz processor (700 MHz or higher recommended)
- Monitor resolution of at least 1024 x 768
- Available USB port
- 512 MB RAM
- 300 MB free disk space
- Internet connection
- Microsoft® Internet Explorer® version 6 or higher
- CD reader

SOFTWARE COMPATIBILITIES

- Microsoft® Outlook® XP
- Microsoft® Outlook® 2003

FREQUENTLY ASKED QUESTIONS

Q: Why doesn't the FLY World application recognize my FLY Fusion™ Pentop Computer even though it is connected?

A: Be sure that your Pentop Computer is powered on. If it isn't on, your personal computer and the FLY World application can't recognize it.

Q: How can I be sure my FLY Fusion Pentop Computer is powered on?

A: The light on your Pentop Computer turns yellow when powered on and plugged into your personal computer. When powered on and not plugged in, the light turns green. And, when it is connected (and charging) but not powered on, the light turns red.

Q: How do I create a Pentop Profile?

A: See [Creating a Pentop Profile](#).

Q: How do I create a FLY World Admin account?

A: See [Creating the FLY World Admin Account](#).

Q: What are FLY World updates, and why should I accept them?

A: FLY World updates are occasional software updates for the FLY World application. You should accept and install these updates in order to stay current with software improvements to the FLY World application, the FLY World Download Store, and your FLY Fusion Pentop Computer.

If there are any updates for your FLY Fusion software, the word "UPDATE" will appear next to the application name on the Pentop tab.

Q: Why does the FLY World application fail to launch?

A: If your personal computer uses a firewall (for example, McAfee Personal Firewall+) and certain ports are blocked, the FLY World application won't launch. You'll need to change which ports are being blocked to resolve this issue.

NOTEBOOKS

- Remember, whenever you plug in your FLY Fusion Pentop Computer, your notebook pages are automatically uploaded to your personal computer from your Pentop Computer. After your pages have been successfully uploaded to your personal computer, they are permanently deleted from your Pentop Computer!
- There are a number of things you can do to improve recognition and conversion of your notes! Always be sure to write numbers and letters carefully and clearly, just like it says in the FLY Fusion Pentop Computer User Manual.
- The default names for your notebooks aren't very descriptive. Try renaming your notebooks something descriptive (see [Renaming FLY Fusion Notebooks](#)).
- To convert a page that has both handwriting (text) and drawings (image), use the Image Selection Tool to ensure that the FLY World application doesn't try to convert your drawings to text (see [Image Selection Tool](#)).
- You can export your notebook pages from the FLY World application as text, images, or both. You can save them as image files, print them, open them in a text editor (like Microsoft Word), or e-mail them to your friends. For more information, see [The Notebooks Tab](#).
- You can search your notebooks for keywords. The FLY World application can find keywords in the names of both your notebooks and notebook pages, and it can also find keywords on the pages themselves. For more information, see [Searching Your FLY Fusion Notebooks](#).
- Before you can e-mail your notebook pages, you have to set up the FLY World application e-mail settings (see [E-mail Settings](#)).

PENTOP

- Any changes you make in the Pentop tab won't actually take effect until you sync your FLY Fusion™ Pentop (see [Syncing Your FLY Fusion Pentop Computer](#)).
- When you add MP3s to your Pentop Computer, be sure to wait patiently while the file is being loaded (see [Adding and Deleting MP3s](#)).
- The FLY World application will recognize only one Pentop Computer connected to your personal computer. However, other Pentop Computers connected to your personal computer will charge, even though they aren't recognized by the application.

DOWNLOAD STORE

- This is where you can find the latest FLY Fusion software available! You can also find product descriptions and user guides for FLY Fusion software through the Download Store tab and online at FLYworld.com.
- When logged on with a Pentop Profile, you can purchase FLY Fusion software if you have value (money) in your Balance. You can also use FLYbucks™ coupons or a credit card to purchase FLY Fusion software from the FLY World Download Store (if you have the necessary permissions set by the FLY World Admin account).

- When logged on with the Admin account, you can use a credit card to add value (money) for Pentop users managed by your Admin account (see **Manage Pentop Users: Add Value**).

FLY WORLD ADMIN ACCOUNT

- **When logged on with the FLY World Admin account, you can do the following:**
 - Select Pentop users to manage
 - Set browsing and purchasing permissions for Pentop users
 - Add value for Pentop users so they make FLY World Download Store purchases.
 - Edit your account, e-mail, and credit card information.
 - Purchase FLY Fusion™ software and subscriptions for Pentop users.
- There can only be one FLY World Admin account for each instance of the FLY World application. To remove an existing Admin account, all you need to do is log on with another authorized Admin account (see **Creating the FLY World Admin Account**). But remember, the Pentop users on that computer won't be available for management by the new Admin account until the former Admin account releases them (see **The Manage Accounts Tab**).

There are three types of accounts that can log on to the FLY World application: Pentop Profile, FLY World Admin account, and Guest Profile.

Pentop Profile

A Pentop Profile is a unique user profile on your computer that associates you with your FLY Fusion Pentop Computer. The FLY World application supports multiple Pentop Profiles; so multiple Pentop Computers can be registered with your copy of the FLY World application. This makes it easy for family and friends—each with his or her own Pentop Computer— to use the same copy of the FLY World application. Each Pentop Profile consists of its own secure library of files (notebooks) and applications (FLY Fusion software). If you log on with one Pentop Profile, you can't see any files or applications from any other Pentop Profiles.

Guest Profile

When you are away from your own personal computer, you can log on as a guest on another personal computer with the FLY World application installed. For example, if you go to a friend's house for a study session, you can click Enter as Guest on the FLY World Log On screen. When logged on as a Guest Profile, you can use some of the file conversion features of the Notebooks tab, such as printing your notebook pages, and share your class notes!

FLY World Admin Account

Typically, a parent owns and manages the FLY World Admin account. There can be only one FLY World Admin account for the FLY World application installed on your personal computer and you must have Internet connectivity to create the account. Only the FLY World Admin account can add value (money) to the Pentop user's purchasing Balance. The FLY World Admin account also sets FLY World Download Store permissions for any managed Pentop Computer users and can reset passwords or promote Guest Profiles to Pentop Profiles.

INSTALLING THE FLY WORLD APPLICATION

You can install the FLY World application using the FLY Fusion™ Installation CD included with your FLY Fusion Pentop Computer or you can download the installer from FLYworld.com.

NOTE: You must have an Internet connection to install the FLY World application.

To install the FLY World application:

- ① Do one of the following:
 - Insert the FLY Fusion Installation CD in your personal computer's CD/DVD drive. The installer application automatically launches and downloads any necessary updates from the Web.
 - Download the FLY World application installer from FLYworld.com. When the download is complete, launch the FLY World application installer.
- ② Follow the on-screen instructions.
- ③ When the installation is complete, you can click Set Up Your Pentop or exit the installer. To set up your Pentop Computer, you must connect it to your personal computer and be sure that it is powered on (see [Creating a Pentop Profile](#)).

UNINSTALLING THE FLY WORLD APPLICATION

You can uninstall the FLY World application from the Windows Start menu.

To uninstall the FLY World application:

- ① From the Windows Start menu, select Programs.
- ② From the Programs menu, select FLY World → Uninstall FLY World.
- ③ On the Application Maintenance window, select the Remove option.
- ④ Click Next.
- ⑤ Select or deselect the "Keep all Pentop Profiles and other existing accounts on this computer" check box.
- ⑥ Click Next.
- ⑦ When the uninstallation is complete, click Exit.

PENTOP PROFILES

OVERVIEW

Use the FLY World application to manage what's on your FLY Fusion™ Pentop Computer. You can:

- Upload notebook pages from your Pentop Computer and print, save, or e-mail them to friends.
- Get updates and purchase FLY Fusion software applications from the FLY World Download Store.
- Customize your Pentop Computer by adding or removing applications and MP3s.

The FLY World application helps you keep what you want on your Pentop Computer and store everything else on your personal computer!

To get started with the FLY World application, create a Pentop Profile for your Pentop Computer and log on to the FLY World application. Just plug your Pentop Computer into your personal computer using the included USB cable, and make sure it's powered on—the FLY World application launches automatically.

CREATING A PENTOP PROFILE

Create a profile for your FLY Fusion Pentop Computer (a Pentop Profile) after installing the FLY World application.

- ① Connect your Pentop Computer to your personal computer using the included USB cable. Make sure your Pentop Computer is powered on. (The light on your Pentop Computer turns yellow when powered on and plugged in.)
- ② The FLY World application launches automatically. You can also launch the application by double-clicking the FLY World icon on your desktop.
- ③ Click the Create Pentop Profile button.
- ④ Enter the user name and password you want to use for your Pentop Profile. This is the user name and password that you'll use every time you log on to the FLY World application. Don't use your real name for your user name.
- ⑤ Re-enter your password.
- ⑥ Select a secret question and enter the answer. If you forget your password, you can answer this secret question to get your password.
- ⑦ Read the user agreement. Then select the check box.
- ⑧ Click Next.
- ⑨ Click Enter FLY World.

You are now ready to use the FLY World application with your FLY Fusion Pentop Computer!

NOTE: You can change your user name, password, and secret question and answer in the General FLY World Settings (see **General Settings**).


LOGGING ON TO THE FLY WORLD APPLICATION WITH A PENTOP PROFILE

When your FLY Fusion Pentop Computer is plugged into your personal computer and powered on, the FLY World application launches automatically. Log on with your Pentop Profile user name and password. You can also launch the FLY World application and log on even if your FLY Fusion Pentop Computer isn't connected.

- ① Do one of the following:
 - Connect your FLY Fusion Pentop Computer to your personal computer using the included USB cable. Make sure your Pentop Computer is powered on. The FLY World application launches automatically.
 - Without connecting your FLY Fusion Pentop Computer, launch the FLY World application from the Windows Start menu or from the FLY icon on the Desktop.
- ② The user name for your Pentop Profile is automatically selected in the User Name drop-down menu. However, if you are logging on without your FLY Fusion Pentop Computer connected, and there is more than one Pentop Profile registered with your copy of the FLY World application, you may have to select your Pentop Profile from the User Name drop-down menu.
- ③ Enter your password.
- ④ If you want, select the "Remember password" option. If this option is selected you aren't required to enter your password each time you log on. If you are logging on to a shared computer, don't select this option.
- ⑤ Click Enter.

NOTE: If you forgot your password, click the Forgot Password? link. Enter the answer to your secret question and click OK. You are reminded what your password is and logged on automatically.

HELP, SETTINGS, AND LOGGING OFF



Help

If you ever need help with the FLY World application, just click the Help link in the upper right corner and browse the Help index to get the help you need.

TIP: You can also right-click anywhere in the FLY World application and select Help from the pop-up menu.

Settings

If you want to change any of the settings for the FLY World application, click the Settings link in the upper right corner. You can change your user name and password; choose to have your password remembered when you log on, and set the e-mail address for e-mailing your notebook pages.

NOTE: Guest and Admin users don't have settings.

GENERAL SETTINGS

The screenshot shows the 'FLY World' application window with the 'Settings' link in the top right corner. The 'General' tab is selected and highlighted with a red circle. The 'General Settings' section contains the following fields: 'User Name:' with a text box; 'Old Password:' with a text box; 'New Password:' with a text box and a blue link 'Choosing a strong password'; 'Re-type New Password:' with a text box; 'Secret Question' with a dropdown menu showing 'If you could have one superpower, what would it be?'; and 'Secret Answer:' with a text box containing four asterisks. At the bottom, there is a checkbox labeled 'Remember my password (Not recommended on shared computers.)' and an 'OK' button.

Open the FLY World Settings window by clicking the Settings link in FLY World. Click the General tab to view the general settings. Once you have made the changes you want, click the OK button to update the settings.

Name and Password

In the Name & Password section, you can type a new Name for your Pentop Profile, and change your password. You can also change your secret question and answer.


Remember Password

If you don't want to have to enter your name and password every time you launch the FLY World application, select the "Remember my password" check box. Selecting this check box isn't recommended on shared personal computers, because it means that your FLY Fusion™ Pentop Computer isn't as secure as it would be otherwise—anyone can log on with your Pentop Profile when this option is selected.

Secret Question and Answer

You can reset your secret question and answer. Select a secret question and enter the answer.

PENTOP SETTINGS



Open the FLY World Settings window by clicking the Settings link in FLY World. Click the Pentop tab to view FLY Fusion™ Pentop Computer Settings. The Pentop Settings tab is only available only if your Pentop Computer is connected to your personal computer and powered on. Pentop settings include date, time, and Pentop country. Once you have made the changes you want, click the OK button to update the settings.

Pentop Date

Set the correct date for your Pentop Computer. This is important for keeping the Pentop Computer's Schedule accurate. Don't forget to click OK.

Pentop Time


Set the correct time for your Pentop Computer. This is important for keeping the Pentop Computer's Schedule accurate. Don't forget to click OK.

NOTE: By default, the "Automatically sync date and time every time I connect my Pentop" check box is selected for you. If this check box is selected, the fields will be populated with your personal computer's date. If you deselect the check box, the fields will be populated with your Pentop Computer's date.

Pentop Country

Select the correct country for your Pentop Computer.

E-MAIL SETTINGS



Open the FLY World Settings window by clicking the SETTINGS link in the FLY World application. Click the E-mail tab to view the E-Mail Settings. Once you have made the changes you want, click the OK button to update the Settings. The FLY World application uses these settings for e-mailing your notebook pages.

E-mail Client

Select your e-mail client from the E-mail Client drop-down menu. The options are Microsoft Outlook, Gmail, AOL, and Yahoo!. For example, if you use Outlook as your e-mail program, select Microsoft Outlook; or, if you use Yahoo! webmail, select Yahoo!. Selecting your e-mail client also automatically sets the SMTP, Port, and SSL Encryption options for your e-mail or webmail program. Don't change these default settings.

NOTE: To use Yahoo! webmail with the FLY World application, you must enable POP in your Yahoo! account.

NOTE: You need to have an e-mail account with Outlook, Gmail, AOL, or Yahoo! to be able to use the e-mail options with the FLY World application. If you don't have an e-mail account with one of these, create one, and then you can use the FLY World application's e-mail options.

E-mail User Name

Enter the user name for your e-mail account. This is usually your e-mail address. If you selected Microsoft Outlook as your e-mail client, you don't need to enter your e-mail user name. However, your e-mail user name is required for webmail clients (Gmail, AOL, and Yahoo!).

E-mail Password

Enter the password for your e-mail account. If you selected Microsoft Outlook as your e-mail client, you don't need to enter your e-mail password. However, your e-mail password is required for webmail clients (Gmail, AOL, and Yahoo!).

SMTP

The default SMTP setting for webmail clients (Gmail, AOL, and Yahoo!) should work and shouldn't be changed. SMTP stands for Simple Mail Transfer Protocol and is how the FLY World™ application sends e-mail using webmail clients.

Port

The default port number for webmail clients (Gmail, AOL, and Yahoo!) should work and shouldn't be changed. The port setting lets the FLY World application contact the mail server for webmail clients.

SSL Encryption

The default selection of SSL encryption for webmail clients (Gmail, AOL, and Yahoo!) should work and shouldn't be changed.

NOTE: The FLY World application doesn't support Microsoft® Outlook® Express 5.0/6.0 or Windows® Mail.


Logging Off

To log off the current user from the FLY World application, just click the Log Off link in the upper-right corner of the application window.

THE NOTEBOOKS TAB

Use the Notebooks tab to manage your FLY Fusion™ Notebooks. All recorded pages of all your FLY Fusion Notebooks are uploaded automatically from your FLY Fusion Pentop Computer to your personal computer and deleted from your Pentop Computer. They are all available in the Notebooks tab.

Using the Notebooks tab, you can sort your notebook pages and search to quickly find the page you want. With the Notebook Page Preview it's easy to view and print, e-mail, save, or convert to text or image and edit any page from any of your notebooks in your default text editor (such as Microsoft Word). And the best part about it is that you can keep every page you've ever recorded on FLY™ Paper right on your personal computer!



CONVERTING YOUR RECORDED WRITING

When you want to e-mail your notebook pages or open them in a text editor (like Microsoft Word), the FLY World application converts your recorded handwriting to text and your drawings to images.

Here are a few tips for making sure your recorded writing converts neatly to text on your personal computer. First, be sure to write letters and numbers neatly and clearly, just like it says in the FLY Fusion™ Pentop Computer User Manual. This will help ensure that your recorded handwriting is correctly converted to text when it is imported into the FLY World application.

Also, you'll no doubt want your drawings to convert to images. Sometimes the FLY World application may incorrectly convert your drawings to text. Usually this will end up a bunch of gobbledygook. You can use the Image Selection Tool to make sure that your drawings are converted to images (see [Image Selection Tool](#)).

Here are some tips for how to write if you want to convert bulleted or numbered lists successfully:

For bulleted lists, try using the following symbols (they are converted more accurately):

*

—

+

—>

=>

.

✓

For numbered lists, try using the following formats:

1) 2) 3)


- OR -

- or -

1. 2. 3.

MANAGING YOUR FLY FUSION NOTEBOOKS

Use the Notebooks pane under the Notebooks tab to select the notebook page you want to see.




You can then do any of the following with the selected pages:

- Print
- E-mail as text or images
- Save as an image file (JPEG, BMP, or PNG).
- Open as a document (RTF).

Selecting FLY Fusion Notebooks


To select any of your FLY Fusion™ Notebooks, click the Notebooks drop-down menu and choose the one you want. The pages of the selected notebook show up in the Pages list.

To see all the pages of all your FLY Fusion Notebooks in the Pages list, select "All my notebooks" from the drop-down menu.




Renaming FLY Fusion Notebooks

By default, notebooks appear in the Notebooks drop-down menu using this naming convention: the word “Notebook” followed by the notebook number (for example, “Notebook 0203”). To rename a notebook, select it in the drop-down menu, click the Rename button, and type the name you want.



Getting FLY Fusion Notebooks from Your FLY Fusion Pentop Computer

If you record writing on your Pentop Computer while it is connected to your personal computer, you can click the Refresh button to upload the new pages, or changes to previously uploaded pages, to the FLY World application.




Writing that is recorded when your Pentop Computer isn't connected to your personal computer is uploaded to the FLY World application automatically the next time you connect your Pentop Computer to your personal computer.


Selecting Pages

You can select (or deselect) one or more pages in the Pages list by clicking the name of the page in the Pages list. The selected page is highlighted in the list and shows up in the Page Preview pane. Use the arrow keys on your personal computer keyboard to move up and down through the list.

To select more than one page in the list, select the check box to the left of the page name for each page you want to select. If a single page is selected, it appears in the Page Preview pane. If multiple pages are selected, the Page Preview pane displays the number of selected pages. Operations are applied to all selected pages.




You can select (or deselect) all of the pages in the Pages list by clicking selecting the Select All check box at the top of the Pages list.



Renaming Pages

By default, notebook pages use this naming convention: "NB," followed by the notebook number and the page number (for example, "NB0203_P08"). To rename a single selected page, click the Rename button and type the name you want.

NOTE: You can rename only one page at a time.




Filtering and Sorting Pages

You can filter the pages in the Pages list by upload date, notebook, and page. Just select the filter category you want from the "Filter by" drop-down menu. If you look at the column to the right of the Name column in the Pages list, you'll see that it changes if you select Upload Date, Notebook, or Page in the "Filter by" drop-down menu. The Name column is always present.

You can sort the Pages list by either column. Click a column header to sort the list by that column. For example, to sort pages by name, click Name at the top of the column.

To reverse the sort order, click the Sort Up/Down button to the right of the sorted column header.



SEARCHING YOUR FLY FUSION NOTEBOOKS

You can search the file names and content of the pages in your FLY Fusion Notebooks by keywords. For example, type the name of the school subject, such as geometry, and the FLY World application will search for the word “geometry” in all your notebook pages.


To search your FLY Fusion Notebooks for keywords:

- 1 Type the keyword for the file name or the content of any page that you want to find.
- 2 Select whether you want to search file names or page contents (or both).
- 3 Click the Search button.

All pages with matching file names appear selected in the Pages list.

Pages with matching content appear with the found keyword highlighted in the Page Preview pane.

NOTE: When the FLY World™ application is confident in the search results, the matches found will be highlighted green. If the FLY World application isn't sure about the search results, the matches found will be highlighted red.




The search results also appear in the Notebooks drop-down menu as “search results.”

Even if you select another notebook, you can always return to your last search results by selecting “search results” from the Notebooks drop-down menu. These search results remain available in the Notebooks drop-down menu until you start a new search or close the FLY World application.

PREVIEWING NOTEBOOK PAGES

When you select a FLY Fusion™ Notebook, all of its Pages appear in the Pages list. When you select a single page in the Pages list, that page appears in the Page Preview pane.




To view the next page in the selected notebook, click the Next Page button (the right pointing arrow to the right of the page name at the top of the Page Preview pane).

To view the previous page, click the Previous Page button (the left pointing arrow to the right of the page name at the top of the Page Preview pane).

Of course, you can always just select a different page in the Pages list to view it in the Page Preview pane.

If you select more than one page in the Pages list, the Page Preview pane displays the number of selected pages.



PRINTING NOTEBOOK PAGES

Select the page (or pages) you want to print in the Pages list, and then click the Print Page button.



TIP: Be sure your personal computer and your printer are correctly set up to print.

E-MAILING NOTEBOOK PAGES

Select the pages you want to e-mail in the Pages list, and then click one of the e-mail buttons. If you use Microsoft Outlook, the FLY World application launches Outlook to e-mail your notebook page(s). If you use a webmail client (Gmail, AOL, or Yahoo!), the FLY World application uses its own webmail editor.

TIP: Make sure that your e-mail settings are correctly configured (see **E-mail Settings**).

NOTE: The FLY World application doesn't support Microsoft® Outlook® Express 5.0/6.0 or Windows® Mail.



Click the E-mail as Text button to launch your default e-mail program or the FLY World webmail editor with the selected pages converted to text and copied into the e-mail message.



Click the E-mail as Image button to launch your default e-mail program or the FLY World webmail editor with the selected page attached as a JPEG file.



NOTE: If you are logged on as a guest, the e-mail options aren't available.

SAVING NOTEBOOK PAGES AS IMAGES


Select the pages you want to save in the Pages list, and then click the Save as Image button.



You can choose where to save the selected image on your personal computer. You can also type a new name for the file and select the file format you want (JPEG, BMP, or PNG).

OPENING NOTEBOOK PAGES AS DOCUMENTS

You can open selected pages as a document in your default text editor (such as Microsoft Word). The FLY World™ application exports pages in Rich Text Format (RTF). Select the pages you want to open in your text editor, and then click the Open as Document button.



A new document opens in your default text editor containing the converted text and images from the selected pages. When multiple pages are selected, they are merged into a single RTF document.

IMAGE SELECTION TOOL

By default, the FLY World application converts your handwriting into text when you choose the Open as Document option (the Image Selection Tool is only for the Open as Document option). You can also make custom selections in the Page Preview pane, which will be converted to images (and not converted to text).

To select an image:




- 1 Click the Select button.
- 2 Click and drag in the Page Preview pane to highlight what you want converted to an image.

If you want, you can make more than one selection.

TIP: You can make multiple selections to select areas that are oddly shaped and don't easily fit within a single rectangular selection.

To clear a selection:




- 1 Click the Clear button.
- 2 Click the highlighted (selected) part of the page to clear the selection.

THE PENTOP TAB

Use the Pentop tab to sync your FLY Fusion™ Pentop Computer with your personal computer. You can swap out applications (FLY Fusion software) and add or remove MP3s to or from your Pentop Computer. There are two main panes in the Pentop tab: Applications and Pentop. If you have a cartridge in your Pentop Computer, the Cartridge pane appears under the Pentop pane. The left pane shows what you have on your personal computer; the right panes show either what you already have on your Pentop Computer or what you want to have on your Pentop Computer and Cartridge after syncing.


NOTE: When moving applications and MP3s to and from the Pentop and Cartridge panes, any changes you make don't take effect on your Pentop Computer until you click the Sync Pentop button.



MY APPLICATIONS

The Applications pane in the Pentop tab lets you manage the FLY Fusion Pentop Computer applications that are stored on your personal computer.

When you purchase a new application through the FLY World Download Store, or install one from a CD, it will appear in the Applications list. You can add any new applications in the Applications list to your Pentop Computer.




The Applications list has several columns that provide information about your applications:

- **Name:** Displays the name of the application.
- **Category:** Displays the category of the application, such as Games, Math, Music, or Foreign Language.
- **Size:** Displays the size of the application in MB.
- **Currently On:** Displays if the application is on your Pentop Computer and if the application is on the inserted Cartridge. This column is empty if the application isn't on either your Pentop Computer or a Cartridge.

TIP: If you have a subscription to an application, you can view the expiration date in a Tool Tip. Just move the mouse cursor over the application's name in the list to display the Tool Tip.

You can sort the Applications list by any of these columns. Just click the column header to sort the list by that column. For example, to sort applications by name, click Name at the top of the column.

To reverse the sort order, click the Sort Up/Down button to the right of the sorting column header.



APPLICATION UPDATES

If there are updates for any of your FLY Fusion™ applications, they will be downloaded to your personal computer when the FLY World application is launched.

Critical updates will automatically be transferred to your FLY Fusion Pentop Computer the next time you click Sync Pentop. Non critical updates won't be transferred to your Pentop Computer unless you select that application to be added to your Pentop Computer and click Sync Pentop.


NOTE: If there are any updates downloaded to your Applications list, the word "UPDATE" will appear next to the application name.

WHAT'S ON MY FLY FUSION PENTOP COMPUTER

The Pentop pane shows what's on your FLY Fusion Pentop Computer when you first log on to the FLY World application with your Pentop Computer powered on and connected to your personal computer. However, as soon as you add or remove applications or MP3s to or from the Pentop pane,

it no longer shows what's on your Pentop Computer. You need to sync your Pentop Computer with your personal computer to update what is actually on the Pentop Computer. This lets you configure what you want on your Pentop Computer before actually committing your changes to your Pentop Computer.


NOTE: The FLY World application will recognize only one Pentop Computer connected to your personal computer. However, other Pentop Computers connected to your personal computer will charge, even though they aren't recognized by the application.



The Pentop list shows which applications and MP3s are on your Pentop Computer (or what will be on your Pentop Computer after you sync your Pentop Computer and personal computer). Each item in the list displays its name, category, and size (in MB).


You can sort the list by any of these columns. Just click the column header to sort the list by that column. For example, to sort applications and MP3s by name, click Name at the top of the column.

To reverse the sort order, click the Sort Up/Down button to the right of the sorting column header.



Managing Memory

The Memory gauge at the bottom of the Pentop pane shows you how much memory you are using and how much is free on your FLY Fusion™ Pentop Computer. The amount of memory each application and MP3 uses appears in the Pentop list. If you have enough free memory, you can add more applications and MP3s to your Pentop Computer. If you are running out of memory on your Pentop Computer, remove selected applications from your Pentop Computer or delete selected MP3s. Once you have freed up memory on your Pentop Computer, you can add other applications or MP3s from your personal computer.




Adding Applications to Your FLY Fusion Pentop Computer

When you get new applications from the FLY World Download Store, or if you install them from a CD, you'll probably want to add them to your FLY Fusion™ Pentop Computer right away. Make sure you have enough memory on your Pentop Computer for any new applications. If you need to free up some memory, remove any old applications that you don't need from your Pentop Computer first (see [Removing Applications from your FLY Fusion Pentop Computer](#)).

To add applications to the Pentop list:

- 1 To select one or more applications to add to your Pentop Computer, select its check box in the Applications list. Applications that are already on your Pentop Computer display  in the Currently On column, so there's no need to select those check boxes.
- 2 Click the Add arrow on the left of the Pentop pane.



The selected applications are added to the Pentop list.

These changes aren't saved to your Pentop Computer until you click the Sync Pentop button (see [Syncing Your FLY Fusion Pentop Computer](#)).

TIP: You can always click the Refresh button  to restore the Pentop pane and see what's actually on your Pentop Computer.


TIP: You can also drag and drop an application from the Applications list to the Pentop pane, or right-click any application in the Applications list to add it to the Pentop pane.

Removing Applications from your FLY Fusion Pentop Computer


If you need to free up some memory on your FLY Fusion™ Pentop Computer to add other applications or MP3s, you can remove any applications you don't need.

To remove one or more applications from the Pentop pane:


- 1 Select the checkbox to the left of the application's name in the Pentop list. You can select multiple checkboxes to select multiple items.



- 2 Click the Remove arrow on the left of the Pentop pane.



To clear all the applications and MP3s in the Pentop list, click the Clear All button.



These changes aren't saved to your Pentop Computer until you click the Sync Pentop button (see [Syncing Your FLY Fusion Pentop Computer](#)).


Applications that have been removed from your Pentop Computer remain on your personal computer, so you can add them back to your Pentop Computer anytime.

TIP: You can always click the Refresh button  to restore the Pentop pane and see what's on your Pentop Computer.

TIP: You can also drag and drop applications from the Pentop pane to the Applications list, or right-click any application in the Pentop pane to remove it from your Pentop Computer. Remember, you still need to click the Sync Pentop button for any changes to take effect.

WHAT'S ON MY CARTRIDGE

The Cartridge pane works just like the Pentop pane. It shows what is on the Cartridge the first time you sync your FLY Fusion™ Pentop Computer with your personal computer. However, as soon as you add or remove applications or MP3s to or from the Cartridge pane, it no longer shows what is on the Cartridge. You need to sync your Pentop Computer with your personal computer to update what is actually on the Cartridge. This lets you configure what you want on your Cartridge before actually committing your changes to your Pentop Computer.




NOTE: The Cartridge pane appears only if your Pentop Computer has a Cartridge.

The Cartridge list shows which applications and MP3s are on the Cartridge (or what will be on the Cartridge after you sync your Pentop Computer and personal computer). Each item in the list displays its name, category, and size (in MB).


You can sort the list by any of these columns. Just click the column header to sort the list by that column. For example, to sort applications and MP3s by name, click Name at the top of the column.

To reverse the sort order, click the Sort Up/Down button to the right of the sorting column header.



MANAGING MEMORY

The Memory gauge at the bottom of the Cartridge pane shows you how much memory you have left on the Cartridge. Applications and MP3s are stored in the Cartridge's memory. The amount of memory each application and MP3 uses appears in the Cartridge list. If you have plenty of free memory, you can add more applications and MP3s to the Cartridge. If you are running out of memory on the Cartridge, you can remove selected applications from the Cartridge or delete selected MP3s. Once you have freed-up memory on the Cartridge, you can add other applications or MP3s from your personal computer.




ADDING APPLICATIONS TO THE CARTRIDGE

When you get new applications from the FLY World Download Store, you'll want to add them to your FLY Fusion™ Pentop Computer or the Cartridge. Make sure you have enough memory on the Cartridge for any new applications. If you need to free up some memory, remove any old applications that you don't need from the Cartridge first.

To add applications to the Cartridge pane:

- 1 To select an application to add to the Cartridge list, select its check box in the Applications list. Applications that are already on the Cartridge display in the Currently On column, so there's no need to select those check boxes.
- 2 Click the Add arrow to the left of the Cartridge pane.



The selected applications are added to the Cartridge list.

These changes aren't saved to your Cartridge until you click the Sync Pentop button (see [Syncing Your FLY Fusion Pentop Computer](#)).

TIP: You can always click the Refresh button (a circular arrow icon) to restore the Cartridge pane and see what's actually on your Cartridge.


TIP: You can also drag and drop an application from the Applications list to the Cartridge pane, or right-click on any application in the Applications list to add it to Cartridge.

REMOVING APPLICATIONS FROM THE CARTRIDGE


If you need to free up some memory on the Cartridge to add other applications or MP3s, you can remove any applications you don't need.

To remove one or more applications from the Cartridge:


- 1 Select the checkbox to the left of the application's name in the Cartridge list.



- 2 Click the Remove arrow to the left of the Cartridge pane.



To clear all the applications and MP3s in the Cartridge list, click the Clear All button.



These changes aren't saved to your Cartridge until you click the Sync Pentop button (see [Syncing Your FLY Fusion Pentop Computer](#)).

Applications that have been removed from the Cartridge are still on your personal computer, so you can add them back anytime.

TIP: You can always click the Refresh button  to restore the Cartridge pane and see what's actually on your Cartridge.

TIP: You can also drag and drop an application from the Cartridge pane to the Applications list, or right-click any application in the Cartridge pane to remove it from your Pentop Computer. Remember, you still need to click the Sync Pentop button for any changes to take effect.


ADDING AND DELETING MP3S

Your FLY Fusion™ Pentop Computer can play MP3s. The Pentop tab lets you add MP3s to your Pentop Computer or Cartridge. You can also delete MP3s that are already on your Pentop Computer or Cartridge.

NOTE: Adding and deleting MP3s from your Pentop Computer or Cartridge is a bit different from adding and removing applications. You can add MP3s that are stored anywhere on your personal computer. And when you remove MP3s from your Pentop Computer or Cartridge, they aren't backed up by the FLY World application and are just deleted. So, be sure to keep backups of your MP3s on your personal computer separately (you can always add them back onto your Pentop Computer or Cartridge later).

To add MP3s to your Pentop Computer or Cartridge:

- 1 Click the Add MP3 button.



- 2 Navigate to the folder on your personal computer where you keep your MP3s.

- ③ Select the MP3s you want and click Open.
- ④ Wait and be patient while the FLY World application imports the selected MP3s.

The selected MP3s are added to the Pentop list or the Cartridge list accordingly.


These changes aren't saved to your Pentop Computer or your Cartridge until you click the Sync Pentop button (see Syncing Your FLY Fusion Pentop Computer).

TIP: If FLY World can't add the music files you've selected to your Pentop Computer, it's usually because the files you've selected are either protected or an invalid MP3 format.

NOTE: In order for MP3s to be playable on your Pentop Computer, the FLY World application needs to "transcode" them. Be patient when adding MP3s to your Pentop Computer—the transcoding process takes time.

To delete MP3s from your Pentop Computer or Cartridge:

- ① Select the MP3s you want to remove by selecting their checkboxes in the Pentop or Cartridge list.
- ② Click the Remove arrow to the left of the Pentop pane or the Cartridge pane depending on whether you want to delete the MP3 from the Pentop list or the Cartridge list.



The selected MP3s are removed from the Pentop pane or Cartridge pane.

These changes aren't saved to your Pentop Computer or your Cartridge until you click the Sync Pentop button (see Syncing Your FLY Fusion Pentop Computer).


NOTE: The MP3s you put on your Pentop Computer ARE NOT saved in the FLY World application. After you delete them, you need to follow the same steps to put them back on your Pentop Computer.

SYNCING YOUR FLY FUSION PENTOP COMPUTER

Any changes you make in the Pentop pane or Cartridge pane aren't made on your actual Pentop Computer or Cartridge until you sync your Pentop Computer and personal computer. This lets you configure what you want (or don't want) on your Pentop Computer and Cartridge before committing to it.

To sync your Pentop Computer and personal computer:

- 1 Make sure your Pentop Computer is turned on and connected to your personal computer using the included USB cable.
- 2 Make any changes you want in the Pentop tab or the Cartridge tab.
- 3 Click the Sync Pentop button.




- 4 Wait for your Pentop Computer and personal computer to sync. Be patient! Don't disconnect your Pentop Computer from your personal computer during the synchronization process. If you disconnect your Pentop Computer from your personal computer while they are synchronizing, your Pentop Computer could become corrupted!
- 5 When the sync is complete, what's on your actual Pentop Computer or Cartridge will match the Pentop tab and Cartridge tab.

NOTE: In order to avoid having to fully rewrite the Pentop Computer each time the Sync Pentop button is clicked, the memory is divided into "slots." Therefore, you may sometimes get the following message when you try to sync:

FLY World couldn't sync your Pentop because the free memory is fragmented. To continue, FLY World needs to reorganize the applications and MP3s on your Pentop.

If this happens, you should click Yes and let FLY World "defrag" your Pentop Computer. This won't cause you to lose any applications or MP3s on your Pentop Computer, unless they no longer exist anywhere on your personal computer.

TIP: You can adjust the size of the Pentop and Cartridge panes by clicking and dragging the slider bar between the two panes.



THE DOWNLOAD STORE TAB

Use the Download Store tab to purchase and download FLY Fusion™ software for your FLY Fusion Pentop Computer. The FLY World Download Store provides easy-to-use tools for searching for, purchasing, and downloading applications (FLY Fusion software) for your Pentop Computer. If you log on to the FLY World application using your Pentop Profile, your unique profile is recognized and you can use any value in your Balance or a credit card to buy applications. Any FLY Fusion software purchased online with (or for) your Pentop Profile is automatically downloaded to your personal computer and made available in the Pentop tab, where you can add it to your Pentop Computer.



NAVIGATING THE FLY WORLD DOWNLOAD STORE


The Download Store tab lets you navigate the FLY World Download Store by clicking links, or by using the Home, Back, Forward, and Refresh buttons located in the upper left corner of the window. These buttons work just like the familiar controls of most Web browsers.

- Click the Home button to return to the FLY World Download Store home page.
- Click the Back button to go back to the previous page.
- Click the Forward button to forward to the next page (if available).
- Click Refresh to reload the current page.




SEARCHING

You can quickly and easily search the FLY World Download Store. Just enter the name of the product in the Search entry field, or a keyword (like "algebra"), and click the Search button.



The results of your search appear on the Search page. You can sort the search results by product name (A-Z or Z-A) or price. When you find the product you want, click the Buy Now button or the Download button (if you have a subscription).



VIEWING PRODUCT DETAILS

For any product, click the product image or its View Details link to get more information about it. The Product Details page gives you a detailed description of the product, including the price, features, instructions, and a video tutorial (if available). You can also view a product's overall rating, and even rate it yourself! Click the Download button or the Buy Now button to purchase or download the product.




BUYING AND DOWNLOADING

The FLY World™ Download Store makes it easy to buy and download any product you want. You can purchase using your FLYbucks™ coupon, a credit card, or the existing value in your Balance.



NOTE: The FLY World Admin account must manage a Pentop user before that Pentop user can start purchasing in the FLY World Download Store (see **Manage Pentop Users: Select Pentop Users to Manage**).

If your Pentop Profile is managed by the Admin account and you have enough value in your Balance to buy the selected applications, just click either the Buy Now or Download button. The appropriate amount is deducted from your Balance, and the selected applications are purchased and downloaded to your personal computer. All downloaded products become immediately available in the Applications list in the Pentop tab. From the Pentop tab you can add your new applications to your FLY Fusion™ Pentop Computer.



TIP: When logged on with a Pentop Profile, your Balance is always visible in the upper right corner of the window.

Adding Value

If you don't have enough value in your Balance to buy the selected applications, the FLY World Admin account log on and add value to your Pentop Profile.

Using Your FLYbucks Coupon

Enter your coupon code in the FLYbucks™ field on the FLY World Download Store home page or during the checkout process.

Subscriptions

You can purchase a one-year subscription to the FLY World application. The subscription gives you access to all available software downloads in the FLY World Download Store.

To purchase a subscription, click the Subscription link in the lower left corner of the FLY World Download Store tab.

Once you have purchased a subscription, you can download any product from the FLY World Download Store anytime during the subscription period.

PERMISSIONS

The FLY World Admin account for the FLY World application can set up permissions so Pentop users can buy products from the FLY World Download Store. A Pentop user can purchase products directly if the permissions for that Pentop user allow it.

The default option for a Managed Pentop Profile is "May Buy." The Admin account can change this selection to "May Not Buy," which means the Pentop user can only browse the FLY World Download Store, but can't purchase anything.

THE FLY WORLD ADMIN ACCOUNT (INTERNET REQUIRED)

OVERVIEW

Typically, a parent owns and manages the FLY World Admin account. There can only be one Admin account for the FLY World application on your personal computer. Your computer must be connected to the Internet in order to create and manage the Admin account. When you log on to the FLY World application as the Admin account, you can:

- Select Pentop users to manage
- Set browsing and purchasing permissions for Pentop users
- Add value to Pentop users' Balance so they can make FLY World Download Store purchases
- Edit your account, e-mail, and credit card information
- Purchase FLY Fusion™ software and subscriptions for Pentop Profiles

The Admin account and your LeapFrog.com account use the same e-mail and password for logon and identification. If you already have a LeapFrog.com account, log on as the Admin for the FLY World application using your LeapFrog.com account e-mail and password.

When logged on with the Admin account, you see a different set of tabs than when logged on with a Pentop Profile: Pentop Users, Manage Accounts, and the Download Store. The Download Store tab behaves much like it does when you log on with a Pentop Profile, but provides additional purchasing options for the Pentop Profiles the Admin account manages. The Manage Accounts tab lets you manage your LeapFrog.com account, as well as set up permissions and value for Pentop Profiles your Admin account manages. The Pentop Profiles tab lets you manage the Pentop Profiles and Guest Profiles registered on your personal computer. You don't need to connect a FLY Fusion Pentop Computer to log on with the Admin account.

CREATING THE FLY WORLD ADMIN ACCOUNT

You can create the FLY World Admin account right after installing the FLY World application. The Admin account is a Leapfrog.com account. Your LeapFrog.com account and the Admin account use the same e-mail and password for logon. There can be only one Admin account for the FLY World application on your personal computer.

- ① Launch the FLY World application.
- ② Click the Enter as Admin button.
- ③ If you already have a LeapFrog.com account, do the following:
 - a. Enter your e-mail address.
 - b. Enter your Password.
 - c. Click Next.

—OR—

If you do not already have a LeapFrog.com account, click the Create LeapFrog Account button and do the following:

- a. Enter your e-mail address.
- b. Re-enter your e-mail address.
- c. Enter your password.
- d. Re-enter your password.
- e. Read the user agreement. Then select the check box.
- f. Click Next.
- g. You are notified that you'll receive an e-mail to approve your new account. Check your e-mail and follow the included instructions.

NOTE: The Admin account must log on and select Pentop users to manage. Pentop users that aren't managed by an Admin account can't purchase anything from the FLY World Download Store.

LOGGING ON TO THE FLY WORLD APPLICATION WITH AN ADMIN ACCOUNT

Every time you launch the FLY World application, you will need to log on with your user name and password.

- ① Launch the FLY World application.
- ② Click the Enter as Admin button.
- ③ Enter your e-mail address.
- ④ Enter your password.
- ⑤ Click OK.


If you forgot your password, click the "Forgot Password?" button. FLY World will e-mail your password to your registered e-mail address.

THE PENTOP USERS TAB

The Pentop Users tab is available only when you log on using the FLY World Admin account. It displays local information about any Pentop Profiles and Guest Profiles on your personal computer. The Pentop Users tab provides the following information for each user:

- The account type.
- The number of notebooks uploaded for that user.
- The total number of pages in all notebooks uploaded for that user.
- The number of times the user has logged on to the FLY World application.
- The date of the last time the user logged on.
- The date of the last time the user uploaded content from his or her FLY Fusion™ Pentop Computer.
- The last time the Pentop user synced his or her Pentop Computer.

For Pentop Profiles, the name and version numbers of the applications the Pentop user has in their library is also displayed.



To select a user, click on the User drop-down menu.


To reset the password for a selected user (Pentop Profiles only), click the Reset Password button. The next time the Pentop user tries to log on, they will be prompted to create a new password.

To delete a selected user's profile, click the Delete Profile button. If you no longer want to manage the deleted Pentop Profile (for example, if you no longer own the Pentop Computer associated with it), you will also need to remove the Pentop user from the list of users that the Admin account manages (see [Manage Pentop Users: Select Pentop Users to Manage](#)).

To sort either the Application Name or Version column, click the column header. For example, to sort applications by version, click Version at the top of the column.


To reverse the sort order, just click the column header again.

To promote a Guest Profile to a Pentop Profile, click the Promote Guest button. Once a guest has been promoted to a Pentop Profile, you'll also need to manage that new Pentop user before they can make purchases in the FLY World Download Store (see **Manage Pentop Users: Select Pentop Users to Manage**).




THE MANAGE ACCOUNTS TAB

The Manage Accounts tab is available only when you log on using the FLY World Admin account. It lets you manage your Admin account.



MANAGE PENTOP USERS: SELECT PENTOP USERS TO MANAGE

Click the Select Pentop Users to Manage link under the Manage Pentop Users menu to select or remove Pentop users your FLY World™ Admin account manages. Any Pentop users you select are your responsibility—you can add value their purchasing balance and provide purchasing permissions for the FLY World Download Store.




To select a Pentop user you want to manage, click the check box next to the Pentop user name under the “Select Pentop users I want to manage” heading. Then click the Update Information button.

To remove a Pentop user that you do not want to manage, click the check box next to the Pentop user name under the “Select Pentop users I do NOT want to manage” heading. Then click the Update Information button.

MANAGE PENTOP USERS: SET PERMISSIONS

Click the Set Permissions link under the Manage Pentop Users Menu section to set the FLY World Download Store permissions for each of the Pentop Profiles your FLY World Admin account manages. The following information appears for each Pentop Profile: the user name, a subscription number (if any), and the expiration date for the subscription (if any). You can also enter the e-mail address for each Pentop Profile. This e-mail address will be used to notify the Pentop Profile user about new products and services depending on the selected notification options. Below are permissions an Admin account can set for Pentop Profiles the Admin account manages:



Download Store Permission:

- “May buy. I will add value for the Pentop user.”
- “May not buy.”

E-mail Permission:

- “Allow new products and services e-mails to be sent to Pentop User”


When you are done setting the notification and permissions options for each Pentop user, click the Update Information button.

MANAGE PENTOP USERS: SUBSCRIPTIONS

Click the Subscriptions link under the Manage Pentop Users menu to purchase subscriptions for any of the Pentop users managed under your FLY World Admin account.

MANAGE PENTOP USERS: ADD VALUE

Click the Add Value link under the Manage Pentop Users menu to add value to any of the Pentop users your FLY World Admin account manages. Only users that have permissions to purchase from the FLY World Download Store are available.



To add value to a Pentop user, select the amount you would like to add to the Balance from the drop-down menu and click the Buy Now button.

YOUR ACCOUNT: ACCOUNT INFORMATION & PREFERENCES

Click the Account Information & Preferences link under the Your Account menu to edit your user name (e-mail address), password, personal information, and e-mail preferences for your FLY World Admin account. After you have made changes to your Admin account, click the Update Information button.

You also can select any of the following options:

- “Please send me news and special offers from LeapFrog.”
- “Please consider me in the Parent Panel, a LeapFrog program for gathering feedback and ideas for games and toys.”

The screenshot shows the 'Account Information & Preferences' page. The left sidebar has a 'Manage Pentop Users' section with links: 'Select Pentop Users to Manage', 'Set Permissions', 'Add Value', and 'Subscription'. Below that is the 'Your Account' section with links: 'Account Information & Preferences' (active) and 'Credit Card Information'. The main content area has a green message: 'Your user name has been updated.' Below this is a section titled 'Update the information and preferences for the Admin account below.' It contains three sections: 'E-mail Settings' with fields for 'E-mail Address' and 'Re-type E-mail', and checkboxes for 'Please send me news and special offers from LeapFrog.' and 'Please consider me in the Parent Panel, a LeapFrog program for gathering feedback and ideas for games and toys.'; 'Password' with fields for 'Old Password', 'New Password', and 'Re-type Password'; and 'Personal Information' with fields for 'First Name' and 'Last Name'. An 'Update Information' button is at the bottom right.

YOUR ACCOUNT: CREDIT CARD INFORMATION

Click the Credit Card Information link under the Your Account menu to add or update your credit card payment information. On the Credit Card Information page, enter the credit card information for the credit card you want to store and use for purchases from the FLY World Download Store. Once you have entered the correct information, click the Update Card button to store the information for your credit card.

To delete credit card information, click the Remove Card button.

NOTE: Stored credit card information is available only to the Admin account—it isn't available to any Pentop users.

The screenshot shows the 'Credit Card Information' page. The left sidebar is identical to the previous screenshot. The main content area has a title 'Credit Card Information' and a note: 'You can get through Checkout even faster by storing secure credit card information here. You will still be able to use a different credit card during the Checkout process.' It contains a form with fields for 'First Name', 'Last Name', 'Address 1', 'Address 2', 'City', 'State/Province', 'Postal Code', 'Country', and 'Telephone'. There are also dropdown menus for 'Card Type' and 'Expiration Date' (Month and Year). At the bottom, there are buttons for 'Remove Card', 'Update Card', and 'Secure Checkout'.

THE ADMIN DOWNLOAD STORE TAB

When you are logged on with the FLY World Admin account, the Download Store tab functions much the same as when you are logged on with a Pentop Profile (except that an Admin account can see the Add Value link under the Products menu). The FLY Fusion™ software you purchase will be available for the Pentop user the next time he or she logs on and navigates to the Pentop tab. Typically, you'll want to add value to the individual Pentop users and allow those Pentop users to make purchases on their own, with or without your approval. For more information on the FLY World Download Store, see [The Download Store Tab](#).

FLY WORLD SUPPORT AND CONTACT INFORMATION

Visit FLYworld.com/support for user guides, video tutorials and other support materials for your FLY Fusion Pentop Computer and FLY Fusion software.

For additional help or to send feedback, contact us at support@flyworld.com.



FLYworld.com

Anoto®

LEAPFROG, the LeapFrog logo, FLY, FLY FUSION, the FLY logo, and FLY WORLD are trademarks or registered trademarks of LeapFrog Enterprises, Inc. © 2007 LeapFrog Enterprises, Inc. All rights reserved.

This product or its use may be covered by one or more of the following United States Patents: 6,548,768; 6,570,104; 6,586,688; 6,663,008; 6,666,376; 6,667,695; 6,674,427; 6,689,966; 6,698,660; 6,719,470; 6,722,574; 6,732,927; 6,836,555; 6,502,756; 6,854,821. U.S. Patents Pending.

Positioning pattern © 1999 Anoto AB

Made in China/Fabriqu  en Chine.

For more information about our products, please contact:

U.S. Office

LeapFrog Enterprises, Inc.
6401 Hollis Street
Suite 100
Emeryville, CA 94608

Canada Office

LeapFrog Canada, Inc.
200 North Service Road W.
Unit #1, Box 357
Oakville, Ontario
Canada L6M 2Y1

U.S./Canada Phone: (800) 701-5327

Visit our website at FLYworld.com

Recommended for ages 8 years and up. Convient aux enfants   partir de 8 ans.